# ManorStone®





ManorStone retaining wall block offer the versatility and ease-of-use that makes them the ideal landscaping product for a wide variety of projects throughout your yard and garden. ManorStone is available in several shapes-including radius and flat face and straight and tapered sided units. Mix and match units to create visual interest, cap your wall, or create staircases. In addition, the bottom of each unit is scored so that you can easily create half units.

ManorStone is perfect for terraced gardens, raised planters, tree rings, stairs and retaining walls up to 3'.





Flat Face 6" x 16" x 12" 15.2 cm x 40.6 cm x 30.5 cm (also available w/tapered sides)

Radius Face 6" x 16" x 12" 15.2 cm x 40.6 cm x 30.5 cm (also available w/straight sides)

# **Dimensions**

	Coverage	Units per Pallet	Coverage per Pallet	Weight per Piece	Weight per Pallet
Radius Face Tapered-Sides	1.5 pcs / ft² (16.2 pcs / m²)	45	30 ft² (2.79 m²)	62 lb. (28 kg)	2,840 lbs
Radius Face Straight-Sides	1.5 pcs / ft² (16.2 pcs / m²)	45	30 ft² (2.79 m²)	75 lb. (34 kg)	3,425 lbs
Flat Face Tapered-Sides	1.5 pcs / ft² (16.2 pcs / m²)	45	30 ft² (2.79 m²)	64 lb. (29 kg)	2,930 lbs
Flat Face Straight-Sides	1.5 pcs / ft² (16.2 pcs / m²)	45	30 ft² (2.79 m²)	79 lb. (36 kg)	3,605 lbs
Corner Unit	1 pc / ft <sup>2</sup>	60	60 ft <sup>2</sup>	56 lb. (25.5 kg)	3,410 lbs

All Weight per Pallet noted above include a 50 lb pallet weight.

Maximum Height: 3' Minimum radius: 2' 8"

### **Available Colors**

For a complete list of available colors, see Mutual Materials stocking products list. For more information regarding custom colors, please contact a sales representative. Custom colors may be restricted by the size of the order or project.

# Project Estimation

NOT TO EXC	WALL LENGTH (0.75 units per lineal foot)						
WALL HEIGHT	COURSES	10 ft	15 ft	20 ft	25 ft	30 ft	35 ft
1'	2	15	23	30	38	45	53
1' 6"	3	23	34	45	57	68	79
2'	4	30	45	60*	75	90	105
2' 6"	5	38	57	75	94	113	132
3'	6	45	68	90	113	135	158

Blocks needed for 5' 5" diameter circle*					
Wall Height	Courses	Blocks			
1' 2		24			
1' 6"	3	36			
2'	4	48			
2' 6"	5	60			
3'	6	72			


<sup>\*</sup> Diameter becomes smaller as you add courses due to 1" set-back per course. This may require cutting blocks to get them to fit.

<sup>\*</sup>EXAMPLE: It takes 60 ManorStone to build a wall 20' long & 2' tall.

#### Installation Instructions (For more specific and detailed instructions, please contact your Mutual Materials sales representative.)

Maximum height: 3' Minimum radius: 2' 8"

- 1. Excavation: First mark the area of the wall with chalk or spray paint and then string a line. Dig out a trench that is a minimum of 9" (230 mm) deep plus one inch for every foot of wall height. Allow 12" (305 mm) of space behind the wall for 34" washed drain rock (this means your trench should be 30" wide). Roots and large rocks must be removed from the trench.
- 2. Base Preparation: The project requires a perforated drain, cover the back and the bottom of the trench with a geotextile to prevent soil from blocking the drainage system. Measure geotextile fabric with excess length of about 12" (305 mm) at the top of the bank, which will be folded over the completed drainage fill.
- 3. Foundation: Install a 4" (102 mm) diameter perforated drain in this foundation and connect it to the existing drainage system. Next, prepare a 6" (152 mm) deep foundation with  $\frac{5}{8}$  minus or  $\frac{3}{4}$  minus crushed rock. Add 1"-2" of  $\frac{5}{8}$  minus or  $\frac{3}{4}$ minus crushed rock, rake smooth and compact with plate compactor. Base rock should have a certain amount of moisture content. Repeat steps until final 6" base elevation is achieved.



NOTE: Before installing additional courses, it is recommended that the installer front fills and backfills the first course with base rock and compacts to ensure stability of the wall.

- 5. Second & Additional Courses: Sweep top of underlying course and stack next course in running bond pattern so the middle of the unit is above the joint between adjacent blocks below. To cut blocks for the ends of the wall or in tight curved sections, use a hammer and chisel to score the unit on all sides. Always wear eye protection when splitting stones. If many cuts are needed, a masonry saw may be the better option to use.
- 6. Backfilling: After each course is laid, backfill behind the wall with 3/4" drain rock. This improves drainage and prevents soil from leaching through the wall face.
- 7. Top Course: Use concrete adhesive to secure the cap course. Apply the adhesive with a caulking gun. Lay the cap down and press firmly. Finish backfilling behind the wall.

ManorStone® is a registered trademark of Mutual Materials Co.

#### Branch Locations

For product information and customer service, call 1-888-MUTUALØ (688-8250)

Western Washington

Auburn Olympia (Tumwater) Bellevue Port Orchard Bellingham Redmond

Burlington Tacoma (Parkland)

Mukilteo

**Eastern Washington** Spokane

**Western Montana** 

Missoula

Western Oregon, SW Washington

Clackamas Salem

Durham Vancouver, WA

Hillsboro

12"

Do not slope soil behind wall.

Geotéxtile

Soil

on site

Perforated Drain

12"

6'

5/8- Base Roc

Max

Wall

Height

